

HOMEDICS®

SoundSpa™ Mini

Instruction Manual & Warranty Information

WARNING

All packing material, such as tags and packaging locks are not part of this product, and should be discarded for your child's safety.

DO NOT PLACE SPEAKERS TOO CLOSE TO EARS. MAY CAUSE DAMAGE TO EAR DRUMS, ESPECIALLY IN YOUNG CHILDREN.

This product is not a toy and is not intended for use or play by children.

- Close supervision is necessary when this product is used by, on or near children, invalids or disabled persons.
- Use this product only for its intended use as described in this manual. Do not use attachments not recommended by HoMedics.
- DO NOT place or store this product where it can fall or be dropped into a tub or sink.
- Do NOT place or drop into water or any other liquid
- Turn off product when not in use.
- NEVER operate this product if it has a damaged cord, plug, cable or housing.
- Keep away from heated surfaces
- Never set on dry surfaces. Do not place on surface wet from water or cleaning solvents

Attention California Residents:

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm.

SAVE THESE INSTRUCTIONS

CAUTION: PLEASE READ ALL INSTRUCTIONS CAREFULLY BEFORE OPERATING

- NEVER leave the product unattended, especially if children are present.
- NEVER cover the product when it is in operation.
- This unit should not be used by children without adult supervision.
- Always keep the product away from high temperatures and fire.

How To Install Batteries:

- Make sure the unit is turned OFF.
- Locate the battery cover. Use a coin to loosen the screw.
- Remove the battery compartment door and the exhausted batteries (if applicable).
- Install 3 new "AAA" batteries following the diagram inside the battery compartment.
- **NOTE:** We recommend using Alkaline batteries for longer battery life.
- Replace the battery compartment door and tighten the screw to secure.

NOTE: It is time to change the batteries when the sounds become faint or stop.

CAUTION: All servicing of this product must be performed by authorized HoMedics Service Personnel only.


Listening to the Sounds:

- Press and hold the POWER button for 3 seconds to power ON. The red LED power indicator will illuminate.
- Select the sound you wish to listen to and press the corresponding button.
- **NOTE:** When the unit is turned on, it will always default to the last sound used.
- To adjust the volume, press the ▲ button or ▼ button to your desired level.
- Press and hold POWER button for 3 seconds to power OFF.

Using the Auto-Timer:

When the power is on and you are listening to a sound you may set a timer so the unit will automatically turn off after 15, 30 or 45 minutes.

- Press the timer button (⌚). The green LED timer indicator will illuminate. Continue to press the timer button to pass through the different settings. **NOTE:** To turn off the TIMER, press the TIMER button until no green LED lights are illuminated.



Battery Precautions:

1. Use AAA alkaline batteries only. Do not use rechargeable batteries.
2. Replace all batteries at the same time.
3. Clean the battery contacts and the contacts of the device prior to battery installation with a dry cloth.
4. Ensure the batteries are installed correctly with regard to polarity (+ / -).
5. Remove batteries from the unit when it is not to be used for an extended period of time.
6. Remove depleted batteries from the unit promptly. Dispose of used batteries safely. Keep all batteries away from children. Batteries are small objects and could be ingested. If swallowed, contact a physician at once. Do not open batteries or dispose of in fire. Do not mix the new and used batteries.

FCC Disclaimer

NOTE: This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: The manufacturer is not responsible for any radio or TV interference caused by unauthorized modifications to this equipment. Such modifications could void the user authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

IC Caution

ICID: RSS-GEN ISSUE 4 DECEMBER 2014

This device complies with Industry Canada License-exempt RSS standard(s).

Operation is subject to the following conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including that may cause undesired operation of the device.

LIMITED 90 DAY WARRANTY

HoMedics sells its products with the intent that they are free of defects in manufacture and workmanship for a period of 90 days from the date of original purchase, except as noted below. HoMedics warrants that its products will be free of defects in material and workmanship under normal use and service. This warranty extends only to consumers and does not extend to Retailers.

To obtain warranty service on your HoMedics product, contact a consumer relations representative for assistance. Please make sure to have the model number of the product available.

HoMedics does not authorize anyone, including, but not limited to, Retailers, the subsequent consumer purchaser of the product from a Retailer or remote purchasers, to obligate HoMedics in any way beyond the terms set forth herein. This warranty does not cover damage caused by misuse or abuse, accident, the attachment of any unauthorized accessory, alteration of the product, improper installation, unauthorized repairs or modifications, improper use of electrical/power supply, loss of power, dropped product, malfunction or damage of an operating part from failure to provide manufacturer's recommended maintenance, transportation damage, theft, neglect, vandalism, or environmental conditions, loss of use during the period the product is at a repair facility or otherwise awaiting parts or repair, or any other conditions whatsoever that are beyond the control of HoMedics.

This warranty is effective only if the product is purchased and operated in the country in which the product is purchased. A product that requires modifications or adoption to enable it to operate in any other country than the country for which it was designed, manufactured, approved and/or authorized, or repair of products damaged by these modifications is not covered under this warranty.

THE WARRANTY PROVIDED HEREIN SHALL BE THE SOLE AND EXCLUSIVE WARRANTY. THERE SHALL BE NO OTHER WARRANTIES EXPRESS OR IMPLIED INCLUDING ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS OR ANY OTHER OBLIGATION ON THE PART OF THE COMPANY WITH RESPECT TO PRODUCTS COVERED BY THIS WARRANTY. HOMEDICS SHALL HAVE NO LIABILITY FOR ANY INCIDENTAL, CONSEQUENTIAL OR SPECIAL DAMAGES. IN NO EVENT SHALL THIS WARRANTY REQUIRE MORE THAN THE REPAIR OR REPLACEMENT OF ANY PART OR PARTS WHICH ARE FOUND TO BE DEFECTIVE WITHIN THE EFFECTIVE PERIOD OF THE WARRANTY. NO REFUNDS WILL BE GIVEN. IF REPLACEMENT PARTS FOR DEFECTIVE MATERIALS ARE NOT AVAILABLE, HOMEDICS RESERVES THE RIGHT TO MAKE PRODUCT SUBSTITUTIONS IN LIEU OF REPAIR OR REPLACEMENT.

This warranty does not extend to the purchase of opened, used, repaired, repackaged and/or resealed products, including but not limited to sale of such products on Internet auction sites and/or sales of such products by surplus or bulk resellers. Any and all warranties or guarantees shall immediately cease and terminate as to any products or parts thereof which are repaired, replaced, altered, or modified, without the prior express and written consent of HoMedics.

This warranty provides you with specific legal rights. You may have additional rights which may vary from country to country. Because of individual country regulations, some of the above limitations and exclusions may not apply to you.

For more information regarding our product line in the USA, please visit: www.homedics.com.

For Canada, please visit: www.homedics.ca.

For Service in the USA

Email: cservice@homedics.com
Monday-Friday 8:30am-7:00pm EST
1.800.466.3342

For Service in Canada

Email: cservice@homedicsgroup.ca
Monday-Friday 8:30am-5:00pm EST
1.888.225.7378

IB-SS1200

HOMEDICS®

Mini spa de sonido™

Manual de instrucciones e informaciyn de garant a

ADVERTENCIA

Todo el material de embalaje, tal como las etiquetas y trabas de embalaje no son parte de este producto y debe ser desechado para la seguridad de su hijo.

NO COLOCAR LOS PARLANTES DEMASIADO CERCA DE LOS OIDOS. ESTO PUEDE CAUSAR DAÑO A LOS TIMPANOS, ESPECIALMENTE EN NIÑOS PEQUEÑOS.

Este producto no es un juguete y no lo dise ado para ser usado por ni os ni para que estos jueguen con  l.

- Es necesario una supervisi n estricta cuando este producto sea usado por ni os o personas con discapacidades, o cerca de ellos.
- Utilizar este producto solamente para el uso para el cual est  dise ado y como se describe en este manual. No utilizar accesorios no recomendados por HoMedics.
- NO colocar ni guardar este producto en donde pueda caer o ser tirado en una tina o lavabo.
- NO colocarlo ni dejarlo caer en agua ni en ningun otro l quido.
- Apague este producto cuando no est  en uso.
- NUNCA poner en funcionamiento este producto si el cable, el enchufe o la carcasa est n da ados.
- Mantenimiento alejado de superficies calientes.
- Colocar lo  nicamente sobre superficies secas. No colocarlo sobre superficies mojadas con agua o solventes de limpieza.
- Atenci n a los residentes de California:

ADVERTENCIA: Este producto contiene sustancias qu micas que el estado de California considera que causan c ncer, defectos cong nitos y otros da os reproductivos.

GUARDE ESTAS INSTRUCCIONES PRECAUCI N: LEER TODAS LAS INSTRUCCIONES CON ATENCI N ANTES DE PONER EN FUNCIONAMIENTO.

- NUNCA deje el producto sin supervisi n, especialmente si hay ni os presentes.
- NUNCA cubra el producto mientras est  en funcionamiento.
- Esta unidad no debe ser usada por ni os sin la supervisi n de un adulto.
- Siempre mantenga el producto alejado de temperaturas altas y del fuego.

C mo instalar las pilas:

- Asegure de que la unidad est  APAGADA.
- Ubique la tapa del compartimento de las pilas. Use una moneda para alinear el tornillo.
- Quite la tapa del compartimento de las pilas y las pilas gastadas (si correspondiera).
- Instale 3 pilas "AAA" nuevas siguiendo el diagrama del interior del compartimento de las pilas.

ATENCI N: recomendamos usar pilas alcalinas para una mayor duraci n de las mismas.

• Vuelva a colocar la tapa del compartimento de las pilas y apriete el tornillo para asegurarlo.

ATENCI N: Cuando el sonido se escucha d bil o se detiene es momento de cambiar las bater as.

PRECAUCI N: todo servicio de este producto debe ser realizado  nicamente por personal de servicio autorizado de HoMedics.

Para escuchar los sonidos:

- Presione y sostenga el bot n POWER (encendido/apagado) durante 3 segundos para ENCENDERLO. El LED rojo indicador de energ a se iluminar .
- Seleccione el sonido que desea escuchar y presione el bot n correspondiente.
- **ATENCI N:** cuando se enciende la unidad, siempre volver  a reproducir el  ltimo sonido usado.
- Para ajustar el volumen, presione el bot n o el bot n hasta el nivel deseado.
- Presione y sostenga el bot n POWER (encendido/apagado) durante 3 segundos para APAGARLO.

Uso del temporizador autom tico:

Cuando el dispositivo est  encendido y est  escuchando un sonido, puede configurar el temporizador para que la unidad se apague autom ticamente despu s de 15, 30 o 45 minutos.

• Presione el bot n TIMER (temporizador). El LED verde indicador del temporizador se ilumina. Siga presionando el bot n del temporizador para pasar por las diferentes configuraciones.

ATENCI N: Para apagar el temporizador, presione el bot n TIMER hasta que no quede ningun luz LED verde iluminada.

